



Attention:

The following tools are required:

- drill $\varnothing 3,3\text{mm}$ and $\varnothing 11,5\text{mm}$
- tap drill M4 and Rp1 / 4

