


- ① - remove the blind plug
 - mount the screwed cable gland
 - lead in the line for the remote control

- ② - plug-on the plug
 - connect the lines

Motherboard



* Box sensor available as:
 Pressure sensor: - Servo control (with and without parallel accustoming)
 - Gradient control (with and without parallel accustoming)
 Suction sensor: - Parallel accustoming without servo- / gradient control

SA2000 Double Box Remote Control with Sensors with Double Priority				Förster Technik GmbH		Zeichnungs-Nr. PL10185		Blatt 1	
				gezeichnet		Datum 16.09.2002		Versions-Nr. a	
Änderung				Ind.		Datum		Name	
				Name jr		Gültig bis:		von 1 Blätter	